



**Boston University**  
**Electrical & Computer Engineering**  
EC463 Capstone Senior Design Project

# **First Prototype Testing Plan**

*EEG-based Brain-Computer Interface*

Submitted to:

Prof. Alan Pisano  
[apisano@bu.edu](mailto:apisano@bu.edu)

by

Team 04  
Brain Force

Team Members:

Alexander Johnson [atjohnso@bu.edu](mailto:atjohnso@bu.edu)  
Brendan Shortall [shortall@bu.edu](mailto:shortall@bu.edu)  
Dayanna De La Torres [dayannat@bu.edu](mailto:dayannat@bu.edu)  
Jonathan Mikalov [jmikalov@bu.edu](mailto:jmikalov@bu.edu)  
Mitchell Gilmore [mgilm0re@bu.edu](mailto:mgilm0re@bu.edu)

Submitted: 11/17/2022

## **Required Materials**

Hardware:

- Handheld digital multimeter and test probes
- Oscilloscope
- Operational amplifiers
- Resistors / Capacitors
- Power supply
- Conductive paste
- Alligator clips

## **Set Up**


The goal of this testing is to ensure that the PCBs we have recently received have adequate connections and to measure an output of a single EEG sensor. In order to test the integrity of the PCB we will be using a handheld digital multimeter to conduct a series of continuity tests across vital components. To test the output of our EEG sensors we will build a simple amplifier circuit with a low pass filter to bring the raw voltage from tens of microvolts to a tens of millivolts range. We will connect the amplified output to an oscilloscope so we can view the sensor output in real time. We have not yet measured an output voltage from an EEG sensor, so any data we can receive will be considered a success. Multiple resistors may be on deck in case our gain is insufficient.

## **Set Up Procedure**

Testing the integrity of the PCB will take essentially zero setup. Just need a multimeter and a few wires to ensure it is working properly. We will also have a schematic of the PCB to ensure we are only testing the connections we are concerned with.

For the second part of our test, the EEG sensor, we will need to design a simple amplifier circuit using an OPamp with a gain of around 1000x. A low pass filter will be applied using a series of capacitors. We will also need to hook up a power supply to the op amp and an oscilloscope to the voltage output. Before connecting the sensor, we can test the functionality of the circuit by using the power supply as an input and ensuring we get the expected output.

The schematic below shows the design of the PCB. We will be using this to decide where to test.



Change R18 to 010 3V Zener CZ50R5203-HF  
Change R11 to 470K  
Add R10 10K to drain Zener

OPERBC: Draft 1-03

Rev 1.0

## **Testing Procedure**

The testing procedure for the PCB includes:

1. Testing the multimeter on a single wire to ensure the continuity function works correctly.
2. Testing each component listed in the score sheet to ensure it is connected correctly. The result of each test will be recorded in the table below.

Testing the EEG Sensor will be done by:

1. Connect the power supply to the OpAmp, and hook up the oscilloscope to the correct location.
2. Use conductive paste to connect a single EEG sensor to a user's scalp.
3. Connect the opposite end of the electrode wire to the OpAmp input.
4. See if we get an output on the oscilloscope.
5. If so, mark a few data points in an excel sheet and take a picture / video of the oscilloscope screen.
6. If we cannot get a reading, make sure all of the wires and connections are hooked up correctly.
7. If still no reading, try increasing the gain.

## **Measurable Criteria**

- Voltage output of OpAmp circuit
- Continuity of printed circuit board
- Number of working PCB components

## **Score Sheet**

<b>Part Name:</b>	<b>Status (Y/N):</b>

